



2. Installation


2.1 Installation requirements



2.2 Wall mounting



2.3 Communication module installation




3. Electrical connection

Please prepare the cable before connecting as follows.


No.	Cable name	Type	Recommend model
1	Protective grounding wire	Single multi-core yellow-green wire	6mm²-10mm²
2	AC output wire	For multi-core multi-core copper wires	6mm²-10mm²
3	PV input wire	PV wire	4mm²-6mm²
4	Battery input wire	Battery wire	4mm²-6mm²
5	Communication wire	RS485	/

Note:
1. Please make sure all switches are in "OFF" position before wiring. For personal safety, please do not operate with electricity.
2. The cable should be cut with a pair of side cutters. The cable should be cut at the terminal or the cable is aluminum wire, please contact our after-sales personnel.

3.1 Grounding




3.2 AC output connection




3.3 DC connection

3.3.1 PV/Battery input terminal installation




3.3.2 Plug in PV/BAT terminal



Note:
1. When installing the PV terminal, please double-check that the PV input voltage and current do not exceed the MPPT limits.
2. When installing the PV terminal, pay attention to the polarity of the PV terminal. The positive and negative poles and the one-to-one correspondence between the terminals must be correct.
3. There is a "click" sound when the terminal is connected, please gently pulling the PV wire to make sure there is no loose or pulling off.

3.3.3 Communication cable installation



4. Connecting Meter

The following table describes how we can connect EASTRON meter (TP4E) to inverter:

Meter Pin NO.	Description	Meter Connection
1/2/3/4	L1/L2/L3/N-In	Grid L1/L2/L3/N
5/6/7/8	L1/L2/L3/N-out	AC connector & Load L1/L2/L3/N
A	RS485A	COM Port Pin 5 RS485A3
B	RS485B	COM Port Pin 6 RS485B3

5. Post-installation check

No.	Acceptance criteria	No.	Acceptance criteria
1	The inverter is installed correctly, firmly and reliably.	6	The RS485 communication cable is installed correctly and firmly.
2	The ground wire connected well and the connection is firm and reliable.	7	The cable tie port is trimmed well without leaving sharp edges.
3	All switches are in the OFF state.	8	All exposed terminals are well protected and there are no vacant ports.
4	All wiring is correct and securely connected.	9	Pay attention to clean up all construction residues.
5	The wiring of the cable is reasonable, meets the requirements, and there is no phenomenon of broken skin.		

6. Power on and off steps


- Note:
Before turning the inverter on, please make sure the PV input voltage and current are within the MPPT limits.
Follow the steps below to turn the inverter on:
1. Switch on the breaker in DC cabinet at the bottom of the inverter.
2. Switch on the Solar AC isolator if the inverter is more than 3 meters away from your switchboard.
3. Switch on the solar supply main switch in the switch board.
4. To shut down your system, follow the guideline reverse order.

7. Status of PV grid inverter

Customer can read more information by push button.

Mark	Describe	Explain
	Single touch	Switch the display interface or the current number plus 1
	Double touch	Enter the setting state or confirm
	Triple touch	Return to the previous display interface
	Long press for 5s	The current data returns to the default value
	Red	Fault
	Green	Normal operation
	Red light flashing	Warning
	Inverter status indicator	When display the basic information of inverter through LCD display screen (PV/AC voltage, PV power, AC current, total power, generating capacity, etc.).

8. Export limitation setting



9. Service and contact

Shenzhen Growatt New Energy Co., Ltd.
Head Office: No. 10, Hengsheng Industrial Park,
Hangsheng Ave., Bao'an District, Shenzhen, China

T +86 0755 2747 1942
E service@growatt.com
W www.growatt.com



Download Manual



Growatt New Energy

GR-UM-240-A-01